



TIGER

NOOK




60cm	80cm	100cm
800926	800927	800928
800931	800932	800933
800936	800937	800938
801045	801046	801047


TOOLS




PART LIST











INSTALLATION




	H	M	W	X
	860 mm	740 mm	660 mm	(60cm) 565 mm
	815 mm	605 mm	605 mm	(80CM) 765 mm
	730 mm	610 mm	510 mm	(100cm) 965 mm




Karton (verpakking)
 Cardboard (packaging)
 Carton (emballage)
 Karton (Verpackung)
 Kartong (emballasje)
 Karton (opakowanie)




Removing front panel



Installing drawer



Removing drawer



Adjusting front panel, drawer

